



DIRECTIONS - IMPORTANT NOTE: Do not open up the control box!

1. Carefully detach the Dial Knob. Do not use force!
 2. Unplug both control light casings from their sockets (hold socket with two fingers and gently pull the plate away from sockets). Then slide the Decorative Steel Plate off the stem.
 3. Mark the 2 holes for mounting the control box, 1 for the stem and 2 more for the control lights.
 4. Drill holes and fasten box to the inside of cabinet.
 5. Slide decorative plate into place.
 6. Mark two holes (vertical or horizontal) for attaching the decorative plate. Remove plate.
 7. Drill marked holes, connect the control lights with their casings and carefully push plate into place.
 8. Affix the plate with two small screws.
- ALTERNATIVELY, E. G. FOR GRANITE SURFACES, YOU CAN AFFIX THE PLATE WITH SILICONE ADHESIVE.
9. Connect the stem extension to stem if needed.
 10. Slide dial knob correctly onto stem (match flat side of stem with